

## MSK 30 and MSK 30/L

### New add-on: Dolby Digital sound (AC3)

Kathrein is now offering Dolby Digital sound (AC3) as a retrofit option for the models MSK 30 and MSK 30/L. The net price for activating the function is EUR 49.00. It will be charged on delivery of the activation file. Both the activation file and the invoice will come by email. The price of EUR 49.00 is due to the very high licence fees for this type of equipment on the part of Dolby Digital plus a low processing fee.

#### For retrofitting the Dolby Digital (AC3) function, the following steps are required:

- Order an activation file by completing the “MSK 30 & MSDK 30/L – Dolby Digital Sound (AC3)” order form and sending it to the following email address: [FriedrichWiersch149@gmail.com](mailto:FriedrichWiersch149@gmail.com)
- The serial number and the software version of the MSK 30 or MSK 30/L can be found in the device information
- To see the information, switch on the MSK and press the VOL/CONFIG button
- Select the configuration menu and click on “Meter Info”

Make sure that your MSK is equipped with the latest firmware. The latest firmware and the loading program are available from our website under:

<https://www.kathrein-ds.com/support/downloadbereich/>

On receipt of your order form, our service team will generate the required activation file and send it to you by email together with the invoice.

#### Activation of the Dolby Digital function using the activation code:

You will need the latest version of S.M.A.R.T., the software tool which is also required for updating the MSK 30 and MSK 30/L software. The free program is available from our website under the above indicated link.

- For activating the option, connect the MSK to your PC using a USB cable
- Switch on the MSK and start the S.M.A.R.T. program on your PC
- Select “**Instrument**” on your tool bar and then “**Connect Instrument**” to connect the MSK to the S.M.A.R.T. program
- As soon as the MSK is connected, select “**Instrument**” again and then press “**Load options**”
- Select the “xxxxx.bin” file for activating the option and open it
- The message “Downloading app options code” appears and the activation starts

**Note:** The activation file is linked to the serial number stored in the device and can therefore not be used for other MSK 30 or MSK 30/L devices.